66E SERIES COMBINATION LOCK
USER OPERATING INSTRUCTIONS
TIME DELAY VERSION

Enter each digit **SLOWLY and DISTINCTLY**. The lock signals at each entry.

TO OPEN THE LOCK

- Enter your combination. The lock will signal twice and the LED will flash at one second intervals
- After delay period, the LED flashes at ½ second intervals and beeps every 10 seconds.
- Re-enter your combination and turn the keypad clockwise to open the lock.

TO CLOSE THE LOCK

- Close the safe door.
- Turn the keypad anti-clockwise until it is straight.

CHANGING COMBINATION

- Open the safe door
- Enter six zeros
- Enter old combination
- Enter new combination TWICE
- **INCORRECT COMBINATION CHANGE** - the lock signals three times and the old combination is still valid.
- **TEST THE NEW COMBINATION SEVERAL TIMES BEFORE CLOSING THE SAFE.**

WRONG TRY PENALTY

- The entry of four consecutive invalid combinations will start a 5-minute delay period. The keypad flashes at 10 second intervals.
- At the end of penalty period, two more consecutive invalid combinations will restart the 5-minute delay period.